



P1R + [tasto] + [led] + [alimentazione] + [connessione]
 [key] + [led] + [power supply] + [connection]




/N: NON LUMINOSO
/R: LED ROSSO
/G: LED GIALLO
/B: LED BLU
/V: LED VERDE
/N: NOT LUMINOUS
/R: RED LED
/G: YELLOW LED
/B: BLUE LED
/V: GREEN LED
/12: 12 V ac/dc
/24: 24 V ac/dc

/BB: piastrina metallica smaltata blu
/BB: blue enamelled metallic plate


				-1	0	1	2	3	4	5	6		
				K	G	B	E	C	A				

/BN: piastrina metallica colore naturale
/BN: natural colour metallic plate

				-1	0	1	2	3	4	5	6		
								A	C				



/M: uscita a morsettiera
/M: terminal board



/F: uscita a filo
/F: wire exit

www.robortelli.com info@robortelli.com

DESCRIZIONE / DESCRIPTION: Pulsante @50 – Modelli @50 Button – Models	DIS: A 11
	REV.: 2
	DATA: 04/11/06